


Unit Information

800 Watts – 1+ HP
2 Yr. Unit Warranty
3 Yr. Motor Warranty
12 mixing speeds with
soft start

WARING
COMMERCIAL
7-Quart Stand Mixer
WSM7Q



WARING COMMERCIAL

503190 Unit Assembly







Illustration #	Part #	Description
1	029128	Top Cover
2	029906	Screw (3 required)
3	029907	Spigot
4	029908	Spigot Seat Plate
5	503294	Front Cover Assembly
6	035166	Middle Cover Assembly <i>(on units after 8/2012)</i>
	503295	Middle Cover Assembly <i>(unit has bracket no longer used)</i>
7	029909	Screw (2 required)
8	029910	Knob
9	503296	Lower Cover Assembly
10	029911	Body
11	029912	Control
12	503297	Gear Box Assembly
13	029913	Pedestal
14	029914	Cord
15	029915	Feet (4 required)
16	029131	Splash Guard
17	029130	Bowl
18	029132	Whisk
19	029134	Paddle
20	029133	Dough Hook
21	029129	Bowl Pad
22	029916	Quadrant
23	503298	Quadrant Spindle Assembly
24	029917	Ground Washer
25	029918	Ground Screw
26	029919	Control Bracket
27	029920	Screw (3 required)
28	029921	Hex Head Bolt (2 required)
29	029923	Timing Belt
30	029924	Spacer (2 required)
31	029925	Felt Pad
32	029918	Screw (4 required)
33	029926	Screw (3 required)

Illustration #	Part #	Description
34	029927	Motor Bushing (3 required)
35	029928	Washer
36	029929	Motor
37	029930	Hinge Retainer
38	029918	Screw (2 required)
39	503299	PC Board Assembly
40	503300	PC Board Assembly Cover
41	029931	Screw (2 required)
42	029932	Quadrant Bracket
43	029918	Screw (2 required)
44	029933	Strain Relief
45	029934	Lower Cord Clamp
46	029918	Screw (4 required)
47	029935	Balance Spring
48	029936	Hinge Pin
49	029937	E Ring
50	029938	Quadrant Spindle Support
51	029939	Head Release Spring



Part No Longer Used

029922 - Bracket
 (no longer available)



Wiring Diagram